Exhibit D Touchpanel Layouts

Exhibit D was updated on 4/8/24. There was text cutoff on the bottom of each picture in the published RFP for the pictures of the control station. This version of Exhibit D show the full text that was cutoff.

Vote Tally

Request Toopeak

Podium Microphone

A

.

2:10

January 26, 2024

Podium OFF

CRESTRON


Request To Speak




Vote Tally




Vote Tally/Request To Speak Summary




Request To Speak Queue



Video Routing




Audio Routing



Move "CONNECT" button to the left; add "MEETING" button

Add additional page accessed when the "MEETING" button is used. Page to include level and mute buttons for "WL 5" AND "WL 6" and "Return to Audio Routing" button with an arrow

Mic Levels




Add WL 5 and 6 to WL mic row.

Move WL 1-4 to the left to center all WL mics on touch panel.

Show level for wireless mics in yellow the same as wired mics.

Mic Mutes



Add Wireless Microphones 5 and 6.

Move wireless 1-4 to the left to center all wireless mics on touch panel. Include WL mic number above wireless mics. Use same font Move "Wireless Microphones" label up to create room for "WL#" labels